

## Table Of Contents

<b>Chapter 1</b>	<b>Installing Hardware and Software</b>	
	<b>Hardware Installation</b>	<b>1</b>
	Installing Video Capture Card (GV Card) to PC	1
	Connecting the BNC Extension Card	3
	Connecting the D-Type Video Extension Cable	4
	Connecting Watchdog	4
	Connecting Real-Time Display Card	5
	Connecting Audio Extension Card	6
	Connecting 16-Channel Audio Recording Card (GV-A16)	6
	Connecting GV-NET Card and GV-NET/IO Card	7
	Connecting Hybrid DVR Card	8
	Connecting GV-NET, GV-IO, and GV-RELAY Modules	11
	Connecting GV-Hub	12
	Connecting GV-Data Capture Box	13
	Connecting IR Remote Control	14
	Connecting GV-Keyboard	14
	<b>Software Installation</b>	<b>15</b>
	<b>USB Dongle Driver for V7.0 Upgrade</b>	<b>16</b>
 <b>Chapter 2</b>	 <b>Configuring Main System</b>	
	<b>System Configuration</b>	<b>19</b>
	Configuring Global Recording Parameters	20
	Adjusting Individual Camera	26
	Setting Up Day-Night Recording Mode	29
	Setting Up I/O Devices	29
	Configuring Hotline/Network Notification	32
	Selecting Screen Layout	34
	Launching GV-System from System Tray	35
	Camera / Audio Install	36
	Setting Up Auto Reboot	36
	Logging System Activities into System Log	37
	Moving PTZ Camera to a Preset Location Upon Alarm Event	39
	Deactivating Alarm and Alert Settings	40
	Popping Up a Camera Window on Motion Detection	40
	Configuring Object Counting	41
	Mapping PTZ Cameras	43

Setting Up Password	44
Sending Alerts thru E-mail Accounts	45
Choosing Video Source	47
Optimizing System Performance	48
Adjusting Video Attributes	44
Switching to Full-Screen View	49
Listening to Live Audio	49
Deactivating Video Lost Beep	50
<b>Start/Stop Monitoring</b>	50
<b>Playing Back Video Files</b>	50
<b>System Log</b>	51
<b>Recording Schedule</b>	54
<b>PTZ Control Panel</b>	57
Auto Switching PTZ Control Panels	57
<b>I/O Control Panel</b>	58
I/O Input Control Panel	58
I/O Output Control Panel	59
<b>Touch Screen Support</b>	59
PTZ and I/O Control Panel	59
Touch Screen Panel	59
<b>Retrieving Images Using Object Index</b>	60
Object Index Setup	60
Live Object Index	62
Object Index Search	63
<b>Detecting Unattended and Missing Objects</b>	64
Detecting Unattended Objects	64
Detecting Missing Objects	66
<b>Object Tracking and Zooming</b>	67
Object Tracking	68
Starting Object Tracking	72
Zooming in Objects	72
Object Zooming	73
Starting Object Zooming	74
<b>Configuring Hybrid Cameras</b>	75
<b>Fast Key Reference</b>	76

<b>Chapter 3</b>	<b>Point-Of-Sale (POS) Application</b>	
	POS System Connection	79
	Setting a POS System	81
	Superimposing POS Data onto Camera Screen	82
	POS Field Filter	84
	Abnormal Transaction Alerts	85
	Codepage Mapping	86
	Searching POS Data	87
 <b>Chapter 4</b>	 <b>Playing Back Video Files</b>	
	<b>Playing Back on ViewLog</b>	89
	Playback Screen Layout	92
	Playback Control Buttons	93
	A to B Playback Mode	93
	Searching a Video Event	94
	Exporting Video	95
	Object Search	97
	Searching and Playing back Motion, Alarm, and POS Event	99
	Advanced Setup	101
	<b>Recycling Option for Video Files</b>	103
	Unmarking All Never-Recycling Flags	104
	Reserving Never-Recycling Flags	104
	<b>Fast Key Reference</b>	105
	<b>Playing Back across Local Area Network (LAN)</b>	106
	<b>Playing Back over Internet</b>	108
	Working with Remote Playback Server at the Server PC	108
	Working with Remote Playback Client at the Client PC	110
 <b>Chapter 5</b>	 <b>Backing Up Video Files</b>	
	<b>Backup Audio/Video Files with Backup System</b>	117
	<b>Backup Audio/Video Files with ViewLog</b>	120
	Quick Backup	120
	Advanced Backup	121
	<b>Backing Up at the Client PC</b>	122
	<b>Deleting Audio/Video Files</b>	123
	<b>Repairing the Damaged File Paths</b>	124

<b>Chapter 6</b>	<b>Viewing Live Video Using WebCam</b>	
	<b>Configuring the WebCam Server</b>	125
	General Settings	126
	Server Settings	126
	Video Settings	127
	RPS Settings	128
	Audio Settings	128
	JPG Settings	130
	IP White List Settings	130
	FTP Server Settings	131
	<b>Starting WebCam at the Client PC</b>	132
	<b>Single View MPEG4 Encoder Viewer</b>	134
	Administrating Host Server	135
	Taking a Snapshot from a Live Video	136
	Pop-up Setup	136
	Exporting Video	137
	PTZ Control	137
	Output Control	138
	Two Way Audio	138
	Data Rate Configuration	138
	DirectDraw Setup	139
	<b>Multi View MPEG4 Encoder Viewer</b>	139
	Working with the Host Server Window	141
	Exporting Video	141
	Taking a Snapshot from a Live Video	141
	PTZ Control	142
	Output Control	142
	Channel Status Information	143
	Camera Polling Function	143
	Two Way Audio	144
	Multi View Configuration	144
	Creating a Quick Connection to a Host Server	145
	Creating a Multiple Host	145
	Camera Status	147
	Host Information	148
	<b>JPEG Image Viewer</b>	149
	<b>Remote Playback on WebCam</b>	149
	Searching and Playing Back Recorded Files	150

	Synchronizing Audio with Video Playback	151
	DirectDraw Setup	151
	Searching Object Index	151
	Advanced Search	152
	<b>Remote Control Using Remote Desktop</b>	154
	<b>Remote Viewing with PDA</b>	155
	G-View Installation	155
	Connecting G-View to GV-Server	155
	Viewing GV-Server Information	157
	<b>Remote Viewing with Mobile Phone</b>	157
	I-Mode Phone	158
	Windows Smartphone	159
	Symbian Smartphone	160
	<b>Fast Key Reference</b>	
	The Multi View Window	162
	PTZ Control in Multi View	163
<b>Chapter 7</b>	<b>E-Map Application</b>	
	<b>The E-Map Editor</b>	165
	<b>Creating an E-Map File</b>	167
	Creating an E-Map File for a Remote Host	167
	<b>Starting E-Map</b>	168
	Setting the Pop-up Map Function	170
	<b>Starting E-Map from a Remote Site</b>	170
	The Remote E-Map Window	171
	Logging in Different Hosts	172
	Configuring the Remote E-Map Window	172
	Viewing Host Information	173
<b>Chapter 8</b>	<b>Live Viewing Using Remote Applications</b>	
	<b>Remote View</b>	175
	Setting Up Remote View	175
	Working With My Favorite	177
	Camera Zoom Function	178
	Playing Back Video Files In Q-View	179
	Preference Settings	180
	Remote PTZ and I/O function	181
	Full Screen View	182

	<b>IP Multicast</b>	183
	Setting up IP Multicast	183
	Starting IP Multicast	183
<b>Chapter 9</b>	<b>Central Monitoring by Center V2</b>	
	<b>Installing Center V2</b>	185
	<b>The Center V2 Window</b>	186
	<b>Creating a Subscriber Account</b>	188
	<b>Configuring Center V2</b>	192
	General Settings	192
	Layout Settings	193
	Network Settings	194
	Record Settings	195
	Dispatch Server Settings	195
	<b>Connecting to Center V2</b>	196
	Normal Mode Setup	196
	Panic Button Setup	199
	<b>Incoming Events to Center V2</b>	200
	Opening the Event Log	201
	Filtering the Event Log	201
	Applying Multiple Filters	202
	Removing Filters	202
	Event Log Settings	202
	<b>Monitoring and Managing Subscribers</b>	203
	I/O Control	203
	Two-Way Audio Control	203
	PTZ Control	204
	Camera Monitor	204
	Viewing Subscriber Information	205
	Controls in the Subscriber Status	206
	<b>Output Alerts</b>	206
	Setting Output Devices	206
	Forcing Output Devices	207
	<b>Notification Settings</b>	207
	<b>SMS Alerts</b>	208
	Connecting to the SMS Server	208
	Sending SMS	208

	<b>E-Mail Alerts</b>	209
	Setting Mailbox	209
	Sending E-Mail	210
<b>Chapter 10</b>	<b>Distributed Monitoring Requests thru Dispatch Server</b>	
	<b>Installing Dispatch Server</b>	211
	<b>The Dispatch Server Window</b>	212
	<b>Creating a Subscriber Account</b>	213
	<b>Advanced Settings</b>	214
	<b>Starting Dispatch Server</b>	216
	<b>Connecting Center V2 to Dispatch Server</b>	216
	<b>Connecting GV System to Dispatch Server</b>	217
	<b>Querying an Event on Center V2</b>	217
	<b>Displaying Real-Time Events of Center V2</b>	218
	<b>Launching the Log Browser</b>	219
	Dispatch Log Browser	219
	Event Log Browser	219
<b>Chapter 11</b>	<b>Central Monitoring by Vital Sign Monitor</b>	
	<b>Installing VSM</b>	221
	<b>The VSM Window</b>	222
	<b>Creating a Subscriber Account</b>	224
	<b>Configuring VSM</b>	224
	System Configuration	224
	Password Settings	226
	Event Log Settings	226
	Notification Settings	226
	Output Settings	226
	E-Mail Settings	226
	<b>Starting VSM</b>	227
	<b>Connecting to VSM</b>	227
	<b>Advanced Settings for Subscription</b>	228
	General Settings	228
	Camera & I/O Settings	229
	System Information Settings	230
	<b>Monitoring Subscribers</b>	230
	Viewing Subscriber Status	230
	Viewing Storage Information	232

	<b>Activating Output Devices</b>	232
	Forcing Outputs of VSM	232
	Forcing Outputs of Subscribers	233
	<b>SMS Alerts</b>	233
	Connecting to the SMS server	233
	Sending SMS	234
	<b>E-Mail Alerts</b>	234
<b>Chapter 12</b>	<b>Short Message Service</b>	
	<b>Installing SMS Server</b>	235
	<b>SMS Server Setup</b>	235
	Device Settings	236
	Server Settings	237
	Account Settings	240
	<b>SMS Log</b>	242
	Setting SMS Log	242
	Viewing SMS Log	242
	<b>Password Security</b>	243
	<b>Connecting GV-system to SMS Server</b>	243
	<b>Setting Mobile Phone Numbers</b>	244
<b>Chapter 13</b>	<b>Useful Utilities</b>	
	<b>Using Dynamic DNS</b>	247
	Installing Dynamic DNS	247
	Registering Domain Name with DDNS	248
	<b>TwinDVR System</b>	250
	Starting TwinServer	251
	Installing TwinDVR	252
	Starting TwinDVR	253
	TwinDVR Settings	255
	<b>Watermark Viewer</b>	256
	<b>Using GV-System in Twin View Display</b>	258
	<b>Windows Lockup</b>	260
	The GV-desktop Screen	260
	GV-desktop Features	261
	<b>Authentication Server</b>	265
	Installing the Server	265
	The Server Window	265



	Creating a DVR List	266
	Editing a User	267
	Starting the Server	268
	Connecting GV System to the Server	269
<b>Troubleshooting</b>		271